Installers 2017 F-250/350 6.2L Switch Gauge Pin Out

| CKP – Crank Position Sensor | Function | OEM Wire Colors (To Solder) | OEM Pins (To Solder) |
|--------------------------------|------------------|-----------------------------|----------------------|
| PLUG A | | | |
| Green/Brown | Crank Position - | Green/Brown | A-69 |
| Yellow/Violet | Crank Position + | Yellow/ Violet | A-70 |
| | | | |

| Function | Connecting side | |
|-------------------------|--|--|
| Fuel Gauge(Sender wire) | Female Disconnect (Pin S on <u>Gauge</u>) | |
| Fuel Gauge (Power) | Female Disconnect (Pin I & +12V on Gauge) | |
| Fuel Gauge (GND wire) | Female Disconnect (Two GND Pins on Gauge) | |
| Flash programming | Connect to Pin 13 in OEM OBDII Connector | |
| - | Fuel Gauge(Sender wire) Fuel Gauge (Power) Fuel Gauge (GND wire) | |

| FUEL SWITCH NOT APPLICABLE ON DEDICATED | | | | |
|---|--------------------------------|-------------------------------------|--|--|
| Fuel Switch | Function | Connecting side | | |
| Brown/Orange | Fuel Switch light (Low) | Female Disconnect (Pin 3 on Switch) | | |
| Pink | Fuel Gauge/Switch (power +12v) | Female Disconnect (Pin 4 on Switch) | | |
| Brown/Green | Fuel Switch light (High) | Female Disconnect (Pin 2 on Switch) | | |
| Black | Fuel Gauge/Switch (GND wire) | Female Disconnect (Pin 1 on Switch) | | |

Last updated: 4/07/17

17F6.2-PINOUT