


MAIN WIRING HARNESS: F250AFCM-BI-WH-V2



REAR HARNESS: F250AFCM-RWH  
GAUGE HARNESS: F250BISWGA  
JUMPER: INJWH



REAR HARNESS  
TO CYLINDER




- TO MAIN HARNESS




SWITCH  
HARNESS  
TO SWITCH



GAUGE HARNESS  
TO GAUGE



INJECTOR HARNESS



TO WEATHER  
PACK TO  
SENSOR



TO  
MOLEX CONNECTOR  
ON MAIN  
HARNESS



TO  
FUEL INJECTOR